

# The Amazing World of Sublimation

## Maker's Squad Tumbler



### Supplies Provided in Kit

- Craft Express Tumbler and Straw
- "Makers Squad" Sublimation print
- 3 Artesprix Markers
- Copy Paper
- Protective Paper

### Extra Supplies Needed

- Craft Express Tumbler Press
- Heat Tape
- Heat resistant gloves
- Artesprix Heat Pad
- Lint Roller

### Optional supplies

- Rainbow of Artesprix Sublimation Markers

- Rainbow of Artesprix Inks
- Blending Brushes
- Various The Crafter's Workshop Stencils

### Instructions

1. Use the lint roller to remove anything that might be stuck to the tumbler surface, like dust or fuzz. Remove the lid and straw
2. Tape down the Maker's Squad Sublimation Print to the tumbler with the image facing the tumbler
3. Wrap tumbler with protective paper and tape in place.
4. Heat tumbler press to 350 - 400 F
5. Insert tumbler in the press and lock into place and heat set for 150 - 210 seconds
6. Remove tumbler from the press using heat resistant gloves and let cool completely on the heat pad
7. Once cool remove the protective paper, tape, and sublimation paper.

### Optional Sublimation Design

1. Option 1 is to use copy paper and use Artesprix Sublimation Markers to draw a design and then follow steps 2 - 7 above.
2. Option 2 is to use The Crafter's Workshop stencil of choice, Artesprix Submilation Inks, and blending brushes to create a design on copy paper and then follow steps 2-7 above.

### Makers gonna Make Tote Bag



## Supplies Provided in Kit

- Tote Bag
- “Makers gone Make” Sublimation print
- 3 Artesprix Markers
- Copy Paper
- Protective Paper

## Extra Supplies Needed

- Craft Express Heat Press
- Heat Tape
- Heat resistant gloves
- Artesprix Heat Pad
- Lint Roller

## Optional supplies

- Rainbow of Artesprix Sublimation Markers
- Rainbow of Artesprix Inks
- Blending Brushes
- Various The Crafter’s Workshop Stencils

## Instructions

1. Use the lint roller to remove anything that might be stuck to the tote surface, like dust or fuzz.
2. Place tote on top of the heat pad
3. Tape down the “Makers gone Make” Sublimation Print to the tote with the image facing the tote.
4. Place a layer of protective paper over print image and tape in place
5. Heat up the Craft Express Heat Press to 380 - 420 F
6. Place heat press over tote and heat set for 35 - 40 seconds
7. Remove the press let the tote cool completely on the heat pad
8. Once cool remove the protective paper, tape, and sublimation paper.

## Optional Sublimation Design

1. Option 1 is to use copy paper and use Artesprix Sublimation Markers to draw a design and then follow steps 2 - 7 above.
2. Option 2 is to use The Crafter’s Workshop stencil of choice, Artesprix Submilation Inks, and blending brushes to create a design on copy paper and then follow steps 2-7 above.

# thank you

## SPONSORS



Scan below for links to supplies used in this this class & to download the cut files

